

OUTDOOR CLEANING WITH PRESSURE WASHERS

For additional information or new ideas visit www.outdoorcleaning.com

Replacing O-rings & Screens

Getting Started



Pry off o-ring with screw-driver

1 REPLACING AN O-RING

To replace an O-ring, use a small flathead screw-driver to pry off the worn or damaged O-ring and discard. Install an O-ring in the same position as the old one.



A new screen

2 CLEANING & REPLACING WATER INLET SCREEN

Cleaning & Replacing Water Inlet Screen. Use a small flathead screwdriver to remove the inlet screen from the hose connector. If the screen is clogged, flush it and the hose connector with clean water. If the screen is damaged, replace it with a new one with the dome-side of the screen pointed outward.



Detach the high-pressure hose

3 REPLACING IN-LINE SCREEN

Cleaning & Replacing In-Line Screen. Detach the high-pressure hose and wand from the spray gun. Remove the O-ring and in-line screen from the wand extension. Flush the screen, spray gun, and wand with clean water from a garden hose to clear debris.



Remove O-ring

3 REPLACING IN-LINE SCREEN

Cleaning & Replacing In-Line Screen. Detach the high-pressure hose and wand from the spray gun. Remove the O-ring and in-line screen from the wand extension. Flush the screen, spray gun, and wand with clean water from a garden hose to clear debris.

